

09.03.2015 LAB - Markko Kard, Olev Tammann, Priit Lahesoo

Wire the computers and switches.

Switch (global) Fa0/7 <--> Fa0/7 Switch

PC1- 4A – 2- 13 (destination/source?)

PC2 – 4A – 2 - 14

Switch

fa0/4 source

fa0/3 destination

10.0.7.3 Source

10.0.2.15 Capturing/Destination

GW: 10.0.7.1

Configure switch:

Switch(config)#monitor session 1 source interface fastethernet 0/2

Switch(config)#monitor session 1 destination interface fastethernet 0/10

Switch#show monitor session 1

On capturing PC:

tcpdump -i eth0 -s 65535 -C 500M -w out.pcap